

CAMO Fasteners

Coastal Waterways and Marine environments

Installation Guidelines



Failure to install CAMO Fasteners in accordance with this installation guide may affect fastener performance and void product warranty.

Salt water environments can create an environment of severe rust and corrosion. Proper fastener selection is extremely important to avoid structural failure in addition to diminished aesthetic quality of the fasteners. Fasteners that are subjected to direct contact with salt water and fasteners that are within reach of exposure to aerosolized salt water carried by the wind from breaking waves are highly susceptible to highly increased corrosion rates.

The following are requirements for choosing the correct CAMO Fastener for your installation.

Within 3000 feet of saltwater shoreline:

316 stainless steel fasteners are required for use within 3000 feet of the shoreline. The following CAMO fasteners are available for installations in those areas.

- CAMO 316 Composite screws - color matched available
- CAMO 316 Edge Screws
- CAMO 316 Edge Screws Collated
- CAMO 316 Bugle head deck screws
- CAMO 316 Trim head Screws - color matched available

3000 feet to 10 miles from shoreline:

Aerosolized salt water can be present up to 10 miles from the body of water increasing the risk of accelerated corrosion. CAMO stainless steel fasteners are required. The following CAMO fasteners are available for installations in this area.

- CAMO EdgeClip
- CAMO EdgeXClip
- CAMO EdgeXMetal
- CAMO Starter Clip
- CAMO Collated 304 Stainless Steel Bright Composite screws (For use with DRIVE)
- CAMO 305 stainless steel Bugle head deck screws
- (CAMO 316 Stainless Steel fasteners are of course also fine for this distance if maximum corrosion resistance is desired)*